

Sewing instructions

Use the width of your sewing machine foot as the width for the seam. Leave a gap of approximately 6.5 centimeters or 2.5 inches in one leg for stuffing. Saw in the label on the opposite leg. Snip into corners, where indicated. Turn the doll inside out and stuff. Hand-sew the stuffing gap in the leg.

Stuffing instructions

Dolls are stuffed through the gap in the leg. Chopsticks are good tools to push in stuffing. Start with the head, then arms, then legs and lastly the chest. The dolls should be firm, but not too firm. If legs or arms flop, more stuffing is needed.

LEAVE 6 CM (2.5 INCH) GAP FOR STUF.

SNIP

SNIP

SEWING LINE - WIDTH OF MACHINE FOOT 2